Canon Pixma MX922 Print Head Alignment

The print head alignment is used to fix any improper installation of the **Canon Pixma MX922 print head** in the Canon Pixma MX922 printer. You can align the print head either manually or automatically. Once you install the print head in the Canon Pixma MX922 printer, the machine aligns the print head automatically. If the automatic process does not satisfy, you can align the print head manually.

Carry On With The Following Topic To Align The Print Head Manually.

- Open the Printer Driver Setup window on your computer.
- Carry on with the following procedure to open the window using the Start or Windows menu.
- Tap the **Start menu --> Control Panel --> Hardware and Sound --> Printers**.

- Right-click the model name of your printer and tap Printing Preferences under the displayed menu.
- Now the Printer Setup window opens.
- Find the Maintenance tab and select it.
- Click the Customer Settings option.
- Click the checkbox near Align Heads Manually.
- Configure the **settings** that display on the screen and tap OK.
- Again, click OK when a confirmation message displays on the screen.
- Ensure that the input tray of the Canon Pixma MX922 printer is loaded with a suitable stack of sheet.
- Check if the Canon Pixma MX922 printer is powered on.
- Click the Align Canon Pixma MX922 Print Head option.
- Go through the instructions on the display.
- Provide the necessary values to be printed and tap OK.
- Confirm the message that displays on the screen by tapping the OK button.
- Now the printer prints the pattern sheet.
- Check the sheet and arrange the print head by adjusting the values.

Canon Pixma MX922 Print Head Replacement

- Before you begin the **print head replacement** process, check if the Canon Pixma MX922 printer is powered on.
- Open the paper output tray by grasping its sides.
- Now open the document cover at the top of the Canon Pixma MX922 printer without touching the panel.
- Raise the ink cover and wait until the Canon Pixma MX922 print head holder slides to its replacement position.
- Never touch the holder until it stops.
- Push the tab present on the ink tank and take it from the Canon Pixma MX922 printer.
- Remove the rest of the cartridges in the same way.
- Press & hold the Stop button until the print head carriage slides to the replacement position.
- Open the inner door and push it to the bottom.
- Remove the **carriage tray** from the printer.
- Hold the top if the center tab and remove the print head.

For read more from this article, please click the below link

https://printer-setup.us/canon-pixma-mx922-print-head